-[Main]- Advanced - Security -	Boot - Exit -
Syst em Ti næ:	[xx: xx: xx]
System Date:	[xx/xx/xxxx]
∏Hard Disk Type:	[xxxxx MB]
CPU Information:	xxxxxxx x. xGHz
Code Mophing Software:	X. X. X- X- XXX
System Menory:	xxx KB
Extended Menory:	xxx MB
BLOS Version:	X. XX
EC/ KBC Versi on:	X. XX

BIOS Utility		
	BIOS default	BIOS value
SystemTime		XX:XX:XX 000 23/ 000 59/ 000 59
System Date		XX/ XX/ XXXX
Hard Disk Type		XXXXXMB
CPU Information		XXXXXX X.XGHz
Code Mophying Software		X.X.X-X-XXX
System Memory		XXX KB
Extended Memory		XXX MB
BIOS Version		XXX
EC/KBC Version		XXX
0 0 000 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		

■ Hard Disk Type HDD □ □ □ □ □ □ □

-[Main]- Hard	Disk Type [xxxxxMB]
Type:	[Auto]
	LBA Fornat
Total Sectors:	XXXXXXXX
Maxi mum Capacity:	xxxxxMB
Multi-Sector Transfers:	[xx Sectors]
LBA Mode Control:	[Enabl ed]
32 Bit I/O	[Di sabl ed]
Transfer Mode:	[FPIO 4/ DMA 2]
Ultra DMA Mode:	[Mode 5]

Primary Master		
	BIOS default	BIOS value
Type	Auto	Auto
Total Sectors		
Maximum Capacity		
Multi-Sector Transfers		
LBA Mode Control		
32 Bit I/O	Disabled	
Transfer Mode		
Ultra DMA Mode		

Maximum Capacity Ultra DMA Mode

- Main -[Advanced]- Security -	Boot - Exit -
Plug & Play O'S:	[Yes]
Internal Pointing Device: Internal NumLock:	[Enabl ed]
Display: Resolution Expansion:	[Both] [Nornal]
□PO Configuration	
Crusoe PTT	[Di sable]

Advanced		
	BIOS default	BIOS value
Plug & Play O/S	Yes	Yes/ No
Internal Pointing Device	Enabled	Enabled/ Disabled
Internal NumLock	Enabled	Enabled/ Disabled
Display	Both	Internal/ External/ Both
Resolution Expantion	Normal	Normal/ Expansion
PCI Configuration		
Crusoe PTT	Disabled	Enabled/ Disabled
	[[Enter] [] [] [] [] [] [] [] [] [] [

-[Advar	nced]-
	PO Configuration
Audi o:	[I RQ9]
POMO A:	[RQ10]
LAN	[I RQ8]
Wireless LAN:	[IRQ4] *Wireless LAN] [
USB 1.1:	[I RQ5]
UBB 2. 0:	[RQ11]
Vi deo:	[RQ10]

PCI Configuration

	BIOS default	BIOS value
Audio	IRQ9	AUTO/ IRQ3/ IRQ4/ IRQ5/ IRQ7/ IRQ9/ IRQ10/ IRQ11
PCMCIA	IRQ10	AUTO/ IRQ3/ IRQ4/ IRQ5/ IRQ7/ IRQ9/ IRQ10/ IRQ12
LAN	IRQ3	AUTO/ IRQ3/ IRQ4/ IRQ5/ IRQ7/ IRQ9/ IRQ10/ IRQ13
Wireless LAN	IRQ4	AUTO/ IRQ3/ IRQ4/ IRQ5/ IRQ7/ IRQ9/ IRQ10/ IRQ14
USB 1.1	IRQ5	AUTO/ IRQ3/ IRQ4/ IRQ5/ IRQ7/ IRQ9/ IRQ10/ IRQ15
USB 2.0	IRQ11	AUTO/ IRQ3/ IRQ4/ IRQ5/ IRQ7/ IRQ9/ IRQ10/ IRQ16
Video		AUTO/ IRQ3/ IRQ4/ IRQ5/ IRQ7/ IRQ9/ IRQ10/ IRQ17

- Main - Advanced -[Security]- Boot - Exit -Set Supervisor Password: [Enter] Set User Password: [Enter] Password on boot: [Disabled] Change Hard Disk Password: [Di sabl ed] Set Hard Disk Password: [Enter]

security		
	BIOS default	BIOS value
Set Supervisor Password		Enter
Set User Password		Enter
Password on boot	Disabled	Enabled/ Disabled
Change Hard Disk Password	Disabled	Enabled/ Disabled
Set Hard Disk Password		Enter

| System | | System |

- Main - Advanced - Security - [Boot] - Exit -

□Boot Sequence

Quick Boot Mode: [Enabled] Qui et Boot: [Enabled]

USB Boot: [Enabled] LAN Boot: [Di sabled] Boot

	BIOS default	BIOS value
Boot Sequence		[Boot Sequence][
Quick Boot Mode	Enabled	Enabled/ Disabled
Quiet Boot	Enabled	Enabled/ Disabled
USB Boot	Enabled	Enabled/ Disabled
LAN Boot	Disabled	Enabled/ Disabled

-[Boot] ----- Boot Sequence -Hard Disk Drive Floppy Disk Drive CD-ROM Drive Network Boot

> Hard Disk Drive Network Boot [

- Main - Advanced - Security - Boot -[Exit]-

Exit Saving Changes Exit Discarding Changes Load Setup Defaults Discard Changes Save Changes